
ROTORAMA

Circle Race Gate

Gemfan · collapsible circular FPV race gate, 78 cm
User manual



Read this manual before first use and keep it for future reference. When unfolded, the gate springs open into its circular shape with force – keep it away from your face.

www.rotorama.com

Contents

1. Product description

1.1 What it is for

1.2 Specifications and package contents

2. Use

2.1 Unfolding the gate

2.2 Positioning and mounting

2.3 Folding the gate

2.4 Safety and care

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal


4. Warranty and rights arising from defective performance

1. Product description

1.1 What it is for

The Gemfan Circle Race Gate is a collapsible circular gate for FPV racing and training. With an outer diameter of 78 cm, the gate is designed to be hung or mounted and is used to mark out a course for small drones; it can also be used for larger 2" drones. Flying through gates helps you practise precise drone control, cornering lines and flying through tight gaps.

The gate is collapsible and easy to carry: when folded it shrinks to a disc approximately 28 cm in diameter, so several gates fit into a backpack. It is suitable for indoor use (gym, hall, living room) as well as outdoors in a meadow or park.




Gate dimensions: outer diameter 78 cm, opening diameter 60 cm, approximately 28 cm when folded.

1.2 Specifications and package contents

Product designation	Gemfan 78cm Circle Race Gate
Shape	circle, collapsible
Outer size	78 × 78 cm
Opening	60 cm diameter
Folded size	approx. 28 cm diameter
Package size	30 × 30 cm
Weight	99 g

Package contents

- 1× collapsible circular gate 78 cm
- 2× mounting strap with holder (according to the manufacturer's packing list)



Package contents according to the manufacturer: gate (1×) and mounting strap with holder (2×).

※ The package does NOT include a stand, poles, bases, pegs or cords for hanging. A drone and other FPV flying equipment are not included either.

2. Use

2.1 Unfolding the gate

① Take the folded gate out of its packaging and hold it firmly with both hands.

② Turn the gate away from your face and from people nearby.


③ Slowly release your grip – the flexible hoop unfolds into its circular shape by itself.

④ Check that the hoop is not twisted and that the cover is evenly tensioned.

2.2 Positioning and mounting

Hang or mount the gate so that the opening is vertical and stable. There are red tabs on both sides of the hoop by which the gate can be attached to two vertical poles, posts, a railing, a branch or another fixed point. Use the supplied mounting straps with holders, or your own cord or cable ties.

- Fasten the gate at least at two points so that it does not rotate in the wind or after a drone impact.
- Outdoors, bear in mind that the gate acts like a sail in the wind – take it down in strong wind.
- Choose a location with no people, animals or fragile objects behind or around the gate.
- When setting up several gates as a course, leave enough space between them for safe passage and turning.



Example of mounting the gate on two poles by its side tabs. The stand and poles are not included.

2.3 Folding the gate

Fold the gate carefully – the flexible hoop tries to return to its original shape and can spring out if handled carelessly.

① Hold the gate with both hands on opposite sides of the hoop.

② Twist both sides towards each other until the hoop turns into a figure of eight.

③ Fold the two loops over each other – three smaller concentric rings are formed.

④ Hold the folded gate firmly and secure it in its bag or with a strap.

2.4 Safety and care

- This product is not a toy. Keep it out of the reach of small children – it contains small parts (mounting straps) and a flexible hoop that can spring out with force when unfolded.
- Keep the gate away from your face and eyes when unfolding and folding it.
- Do not use the gate as a support, a ladder or for hanging other objects.
- After a drone impact, check the hoop and the cover. Do not continue to use a cracked or sharply bent hoop.
- Let a wet or muddy gate dry before folding it; remove dirt with a damp cloth.
- Store it folded in a dry place, away from direct sunlight and heat sources.

3. Information for the EU and Czech Market

The information in Chapters 3 and 4 describes the situation in the Czech Republic. If you use the product in another country, the law of the country in which the product is operated is decisive – follow the regulations of that country.

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorama.cz
Phone	+420 252 252 098
Website	www.rotorama.com

Manufacturer: GEMFAN HOBBY CO., LTD., No. 1501, Building E, Yinzhou Technology Incubation Park, Xueshi Road 655, Yinzhou District, Ningbo, Zhejiang, China, e-mail contact@gemfanhobby.com.

3.2 Disposal

- The product contains no electronics or batteries and is not electrical equipment.
- Dispose of the unwanted gate and mounting straps in accordance with the waste sorting rules applicable where you use the product (municipal waste system, collection yard).
- Sort the packaging by material into the appropriate recycling containers.
- Proper disposal helps protect the environment and contributes to the reuse of secondary raw materials.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.