



Battery Strap 16x200

Silicone battery strap
User manual



Read this manual before first use and keep it for future reference.

Rotorama, s.r.o. · www.rotorاما.com

Contents

1. Product description

1.1 Purpose

1.2 Technical data and package contents

2. Use

2.1 Securing the battery

2.2 Inspection, maintenance and replacement

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

3.2 Disposal

4. Warranty and rights arising from defective performance

1. Product description

1.1 Purpose

The Rotorama Battery Strap is a strap for securing the flight battery to the frame of a multicopter. The strap fastens with hook-and-loop (Velcro) and, for greater durability, is fitted with a metal buckle through which the free end of the strap is pulled and tightened.

One side of the strap is coated with a non-slip silicone layer. This side rests against the battery and helps keep it in place even during aggressive manoeuvres.



Strap closed into a loop – metal buckle and hook-and-loop fastener

1.2 Technical data and package contents

Product designation	Rotorama Battery Strap – Silikonový 16x200
Width	16 mm
Length	200 mm
Weight	3.8 g
Fastening	hook-and-loop, metal buckle
Surface	one side with a non-slip silicone layer
Package contents	1× battery strap
Not included	battery, frame or drone



Side with the non-slip silicone layer

2. Use

2.1 Securing the battery

- ① Thread the strap through the battery strap slots in the frame so that the silicone side faces upwards – towards the battery.
 - ② Place the battery on the frame (or on a non-slip pad, if used) and centre it according to the multicopter's centre of gravity.
 - ③ Pull the free end of the strap over the battery and thread it through the metal buckle.
 - ④ Tighten the strap firmly, fold it back and press the hook-and-loop fastener together along the full overlap.
 - ⑤ Check that the battery does not slide on the frame and that the strap does not reach into the path of the propellers.
- Tighten the strap firmly but reasonably – excessive tension can deform a Li-Po battery.
 - The power and balance leads must not be pinched under the strap and must not hang loose into the path of the propellers.
 - The strap must be long enough to go around the battery and the frame plate while still leaving a sufficiently long hook-and-loop overlap.

2.2 Inspection, maintenance and replacement

- Before every flight, check that the hook-and-loop fastener is clean and holds firmly and that neither the strap nor the buckle is damaged.
- Keep the hook-and-loop fastener free of dust, grass and sand – dirt reduces its grip.
- Do not use a torn, frayed or hardened strap, a bent buckle or a worn hook-and-loop fastener; replace the strap with a new one.
- Do not expose the strap to high temperatures or to sharp edges of the frame that could cut through it.

❖ **A battery coming loose in flight can lead to loss of control of the multicopter. Therefore, check the strap before every flight.**

3. Information for the EU and Czech Market

3.1 Importer and responsible person in the EU

The product is placed on the European Union market by the importer stated below, who is at the same time the responsible person within the meaning of Article 16 of Regulation (EU) 2023/988 of the European Parliament and of the Council on general product safety (GPSR).

Importer / responsible person in the EU	Rotorama, s.r.o.
Company ID (IČO)	051 57 692
VAT ID (DIČ)	CZ05157692
Registered office	Okrajová 1351, 674 01 Třebíč, Czech Republic
E-mail	info@rotorاما.cz
Phone	+420 252 252 098
Website	www.rotorاما.com

3.2 Disposal

- The product contains no electrical or electronic components and no batteries; the rules for the take-back of electrical equipment do not apply to it.
- Dispose of a worn strap in accordance with the waste sorting rules of your municipality. The metal buckle can be separated and handed in for metal collection.
- Sort the product packaging according to the type of material.

4. Warranty and rights arising from defective performance

The rights and obligations of the contracting parties are governed by Czech law, in particular by Act No. 89/2012 Coll., the Civil Code, and Act No. 634/1992 Coll., on consumer protection.

- The seller is liable to the buyer for the product being free of defects on receipt. If the buyer is a consumer, a defect may be notified **within two years of receipt** of the product (Section 2165 of the Civil Code).
- If a defect appears within **one year** of receipt, the product is deemed to have been defective already at the time of receipt (Section 2161(5) of the Civil Code).
- When purchasing online, a consumer has the right to **withdraw from the contract within 14 days** of receiving the goods without giving a reason (Section 1829 of the Civil Code).
- Claims should be made with the retailer from whom you purchased the product. The importer's contact details are given in Chapter 3.1.
- The competent body for out-of-court settlement of consumer disputes is the **Czech Trade Inspection Authority**, Štěpánská 796/44, 110 00 Prague 1, www.coi.cz.

Wear of the strap, the hook-and-loop fastener and the buckle resulting from normal use is not a defect of the product.